

Brake Adjusters

Rounded off with age (No - not you, your rear brake adjusters).

Not enough edges/ corners left on your rear brake adjusters of your Citroen Special = grazed appendages and not brake adjustment.
A solution is to cut two x 1-inch of 12mm square bar (half-metric speak) and weld end-on to the 14mm adjuster bolt head. Now use a 12mm open-ended spanner to adjust the brake shoes.

P.S The heat of welding helps free stuck adjusters.

Anthony Shelton (Lomax Pilot) Member No. 230

